


# Curing of unsaturated polyester resins



# PEROXIDES FOR CURING OF UNSATURATED POLYESTER RESINS

## CURE PERFORMANCE AT 80°C COMPARISON

CURE PERFORMANCE AT 80°C  
IN A MEDIUM REACTIVITY ORTHOPHTHALIC RESIN



Tradename	Peroxide quantity	Cobalt 6% quantity	Gel time (min:s)	Cure time (min:s)	Peak exotherm (°C)	Pot life at 30°C (hours)
Luperox® K2	2 phr	No cobalt	05:47	07:35	201	06:00
Luperox® K21	2 phr	No cobalt	05:48	07:03	203	06:00
Luperox® 26M70	2 phr	No cobalt	08:36	10:26	190	>24
Luperox® ANS50G	2 phr	No cobalt	12:37	13:22	197	>24
Luperox® DP10G	2 phr	0.25 phr	05:17	05:58	190	14:09
Luperox® DP40	2 phr	0.25 phr	04:40	05:28	204	10:30

### CONDITIONS OF EXPERIMENT

Resin: medium reactivity orthophthalic resin  
Peroxide: 2%  
Cobalt (6% solution): depending on test  
Resin initial temperature: 25°C  
Testing temperature: 80°C  
Resin sample: 25 g

Application guidelines		
Solvent	Active Oxygen (%)	Recommended maximum storage temperature (°C)
		<div><div></div> Recommended</div> <div><div></div> Other possible application</div>
		Gel coats & top coats
		Hand lay-up
		Spray-up
		Compound marble (blocks)
		Polymer concrete
		Casting
		Resin transfer moulding (RTM)
		Vacuum moulding / infusion
		Centrifugal casting
		Filament winding
		Panels & sheets
		Compound quartz (slabs)
		SMC / BMC / DMC
		Pultrusion
		Varnishes
		Putties
		Vinylester & bisphenol resins
		Acrylic resins
		Buttons
		Paper Impregnation

Application guidelines

Solvent

Active Oxygen (%)

Recommended maximum storage temperature (°C)

Recommended

Other possible application

Gal coats & top coats

Hand lay-up

Spray-up

Compound marble (blocks)

Polymer concrete

Casting

Resin transfer moulding (RTM)

Vacuum moulding / infusion

Centrifugal casting

Filament winding

Panels & sheets

Compound quartz (slabs)

SMC / BMC / DMC

Pultrusion

Varnishes

Putties

Vinylester & bisphenol resins

Acrylic resins

Buttons

Paper impregnation

METHYL ETHYL KETONE PEROXIDES

Luperox® K18

Dimethyl phthalate

9.9


25










Very high activity MEKP. Gives fast gel and cure time for a variety of ortho and isophthalic resin systems.

</

## ↓ KETONE PEROXIDES FOR CURING OF UNSATURATED POLYESTER RESINS CURE PERFORMANCE AT ROOM TEMPERATURE COMPARISON

**CURE PERFORMANCE AT 25°C, 2% PEROXIDE, 1% Cobalt-1%  
IN A MEDIUM REACTIVITY ORTHOPHTHALIC RESIN**



Tradename	Gel time (mins)	Cure time (mins)	Peak exotherm (°C)
 Luperox® K15/K1G	09:24	17:21	146
 Luperox® K18	06:52	13:29	150
 Luperox® K10	07:32	15:01	147
 Luperox® K12G	27:48	42:23	135
 Luperox® K3	06:48	11:10	162
 Luperox® K4CE	08:34	21:21	126
 Luperox® Z11S/Z11G	09:33	15:57	161
 Luperox® Z13S	08:52	14:39	158
 Luperox® Z390	08:22	12:08	166

## CONDITIONS OF EXPERIMENT


Resin: medium reactivity orthophthalic resin  
 Peroxide: 2%  
 Cobalt (1% solution): 1%  
 Resin initial temperature: 25°C  
 Resin sample: 50 g



# KETONE PEROXIDES FOR CURING OF UNSATURATED POLYESTER RESINS

## CURE PERFORMANCE AT ROOM TEMPERATURE COMPARISON

CURE PERFORMANCE AT 25°C, 2% PEROXIDE, 1% Cobalt-1%  
IN A MEDIUM REACTIVITY ORTHOPHTHALIC RESIN



Tradename	Gel time (min:s)	Cure time (min:s)	Peak exotherm (°C)
Luperox® K1S/K1G	09:24	17:21	146
Luperox® K18	06:52	13:29	150
Luperox® K10	07:32	15:01	147
Luperox® K12G	27:48	42:23	135
Luperox® K3	06:48	11:10	162
Luperox® K4CE	08:34	21:21	126
Luperox® Z11S/Z11G	09:33	15:57	161
Luperox® Z13S	08:52	14:39	158
Luperox® Z390	08:22	12:08	166

### CONDITIONS OF EXPERIMENT

Resin: medium reactivity orthophthalic resin  
Peroxide: 2%  
Cobalt (1% solution): 1%  
Resin initial temperature: 25°C  
Resin sample: 50 g

## SAFETY HANDLING OF ORGANIC PEROXIDES



**1** Observe exact **storage temperature** indicated on product label.



**2** Keep away from sources of ignition and heat.  
Store in a cool dark place - well **separated** from accelerators and other flammable material.



**3** **Danger of explosion:** never mix peroxides and accelerators together; add each component separately to the resin.

**4** Store peroxides in **original containers**. Contact with rust, ash, dirt, accelerators and many other chemicals can cause violent decompositions.

**5** Even in diluted form peroxides have a **corrosive** effect on the skin and eyes. Always **wear gloves** and protective **goggles** when handling peroxides.



**Smoking and naked flames strictly prohibited in work and storage areas!**

## IN CASE OF ACCIDENTS: FIRST AID



### EYES

In case of eye contact, rinse immediately with large quantities of water for at least 10-15 minutes. Contact an ophthalmologist immediately.



### INGESTION

In case of accidental swallowing, do not induce vomiting. Administer water in small sips and charcoal tablets in addition. Call a doctor immediately.



### SKIN • BODY

Remove soaked clothes immediately.  
Wash skin with plenty of water and cover skin with sterilized bandages. Seek medical advice.



### SPILLAGE

If peroxide is spilled, absorb with inert material e.g. Vermiculite or clean sand immediately and destroy in accordance with local regulations.



### FIRE

Suitable extinguishers are waterspray and foam.  
In case of large fires: Fight fire from safe distance (10-15 m). Cool containers/tanks with water spray. Call fire brigade immediately.

**Consult Safety Data Sheets before handling organic peroxides**

A global chemical company and France's leading chemicals producer, **Arkema** is building the future of the chemical industry every day. Deploying a responsible, innovation-based approach, we produce state-of-the-art specialty chemicals that provide customers with practical solutions to such challenges as climate change, access to drinking water, the future of energy, fossil fuel preservation and the need for lighter materials. With operations in more than 40 countries, some 14,000 employees and 10 research centers, Arkema generates annual revenue close to 6.5 billion, and holds leadership positions in all its markets with a portfolio of internationally recognized brands.

The information contained in this document is based on trials carried out by our Research Centres and data selected from the literature, but shall in no event be held to constitute or imply any warranty, undertaking, express or implied commitment from our part. Our formal specifications define the limit of our commitment. No liability whatsoever can be accepted by Arkema with regard to the handling, processing or use of the product or products concerned which must in all cases be employed in accordance with all relevant laws and/or regulations in force in the country or countries concerned.

**ARKEMA**  
INNOVATIVE CHEMISTRY